



SUSHI BOARD SET

SUSHI BOARD SET

SET SUSHI BOARD



		cm	cm		€	€
4853 020	20 x 11	2	6	4,10	24,60	
4853 026	26,5 x 9	2	6	4,80	28,80	



4853 020



4853 026

FISCHELLER SET

FISH PLATE SET

SET D'ASSIETTES À POISSON



		cm	cm		€	€
4852 021	21 x 16	2	6	6,00	36,00	
4852 035	35 x 26	3	3	15,00	45,00	



4852 035

FISCHELLER SET

FISH PLATE SET

SET D'ASSIETTES À POISSON



		cm	cm		€	€
4907 370	37,5 x 25	2	6	14,00	84,00	




SUPPENTASSE UND UNTERTASSE SET

SOUP CUP AND SAUCER SET

SET TASSE À SOUPE ET SOUCOUPE



				cm		€	 €
A	4963 026	Suppentasse Soup bowl Tasse à soupe	260	5,5	6	3,90	23,40
B	4960 003	Suppenuntertasse Soup saucer Soucoupe pour soupe		2	6	3,50	21,00



Mit Henkelgriffen • With handles • Avec poignées